

Micro-Touch 1500 Scale Recall Notice

February 23, 2022

Lyman Products Customers,

It has come to our attention that some recent production Micro-Touch 1500 scales produced in 2020 & 2021 had a circuitry change which may result in certain scales improperly reading trickled powder. This could potentially produce a lower scale reading than the actual amount. For this reason, we are initiating a recall and providing repair or replacements for some of these scales. **If your scale was purchased in 2020 or 2021**, please follow the instructions below to determine if your scale is affected and requires repair or replacement.

Micro Touch #7750700

HOW TO CHECK YOUR SCALE:

Affected scales can be identified during the calibration process:

1. Be sure your Micro-Touch 1500 scale is plugged in to an active wall outlet or has fresh AAA batteries installed. See Operating Instructions for set-up guidance.
2. Hold down the on/off button to start the calibration process
3. The scale display will show either a "0" or "CAL", and then switch to "100" to indicate to place the calibration weight on the scale.
4. **SCALES AFFECTED BY THE RECALL WILL SHOW "CAL". THESE SCALES MUST BE RETURNED TO LYMAN PRODUCTS.**
5. Scales that show "0" are not affected by the recall and may remain in use.

If your scale shows "CAL", please call Cabela's Canada at 1-800-265-6245 for refund or replacement.

Lyman Products is committed to ensuring our products meet the high quality standards that our customers have come to rely on. We apologize for any inconvenience this product recall causes and want our distribution partners to know that the safety of our customers is our first priority.

Sincerely,

Lyman Products